

17741

W-TILE REPLACEMENT FOR CURVED TILE ROOFS



A DIVISION OF QUICKSCREWS INTERNATIONAL CORP

TABLE OF CONTENTS

3

SPEC SHEET

QTY & MEASUREMENT INFORMATION

4

INSTALLATION INSTRUCTIONS

STEP-BY-STEP-INSTALLATION GUIDE

SPEC SHEET

Part #	Box Quantity
17741	Galva W-Tile, Black (20)



INSTALL INSTRUCTIONS



RECOMMENDED MATERIALS

- Tin snips
- QuickBOLT mount

INSTALLATION INSTRUCTIONS

1. Remove tile
2. Install QuickBOLT mount
3. Snip tile replacement at hook edges
4. Place tile replacement